

Interior Electrics

Boot lid doesn't close fully

Problem

The boot lid doesn't fully open/lifts briefly, reverses and closes again. or

The boot lid doesn't close fully/the closing starts briefly, stops, reverses just before closing and opens again.

Technical background

The boot lid drive doesn't provide enough torque for opening/closing the boot lid (solenoid clutch in the drive slips through).

Production change

Modified clutch lining on the Magnet clutch from part version 35S.

From 06/05 Chassis No. 4E 6N 006915

Resolution

try to lubricate the hinge with universal oil spray

If this does not work you may need to Fit a new drive - Part No. **4E0 827 852 E** with parts version 35S or higher. The

Unique solution ID: #1024

Author: Nick

Last update: 2013-02-22 21:01